



PO Box 129
Ashley IN 46705
260-281-9976
877-858-9847

www.conestogacovers.com
info@conestogacovers.com

Care and Cleaning of your Conestoga Covers

Proper care and cleaning should be taken to ensure the life of your Conestoga Cover.

On a routine basis, excessive dirt should be lightly brushed from the fabric, and then the fabric should be sprayed with water and allowed to air dry.

For more thorough cleaning, lightly brush fabric, spray with water, and then apply a gentle, **non-detergent** soap. Let the solution stand for 10 to 20 minutes, taking care not to let it dry. Then rinse thoroughly and air dry.

Treatment with a water repellent after cleaning may be required to restore the original level of water resistance.

Conestoga Covers frames can be cleaned with the same methods as the cover. Extra scrubbing with brush or cloth may be necessary to remove build up from the water.